IWble 工具烧录域名操作

1、在手表快捷菜单-->设置-->蓝牙模式,先将手表进入蓝牙模式



2、安装我们提供的 apk 安装包



3、安装成功后打开 app 是显示空白,点击右上角;按钮,显示菜单



4、点击 Switch Sdk Type,选择 PROTOBUF 协议



5、选择后, APP 会返回到上一页, 再点击右上角 按钮, 选择扫描



6、进入蓝牙搜索页面,点击设备蓝牙名称进行连接,连接成功后进入设备页面

← 扫描		= 1.24.0802	
F1PLUS-9023	-51 >	设备	
F1PLUS-4711	-56 >	设备名称:H102C-3728 设备地址:50:C0:F0:EB:35:15 连接状态:连接 由地:18	
D H102E-3135	-58 >	版本:54.2.0.8 model:H102CN sn:H102CX100240R01000011	
H102C-3728	-60 :	心家	
ZP100-D10F	-62 >	心率:0 一····································	
F1PLUS-8181	-63 >	睡眠	
F1PLUS-0663	-66 >	总睡眠时长:0h0min % 浅睡眠时长:0h0min 深睡眠时长:0h0min	
F1PLUS-3061	± ¹⁰³⁸ 6689 −69 >		
VS-D1-5DFE03	-72 >	表盘设置	
Con-4851	-72 >	中医数据	
- 0			

7、点击设备,进入手环设置页面,选择数据上传地址

手环设置	数据上传地址	
) 动提醒体验模式	请输入地址	
坐機罐 > -====== >	42 (4)	¥
	Q.	2
-健润量健康 >		
数据上传地址 王四法 5589		
B皮单位 >		
豊用手 >		
音言 王 (13)3 55355		
周件升级		
₽₩ >		
2置通讯录 (10)3 5550 >		

8、进入域名更改地址页面,将新的域名输入到地址框或者进行粘贴,输入成功后,点击发送, app 提示发送成功就是写入完成,需要将手表重启,重启后在后台确认能否收到设备数据上传。